


Pipe Fittings • PRB/PSE/PST/PBT



Reducing Bushing

PRB



Connects Female Pipe To Male Pipe

Part No.	Pipe Size		Dimensions		
	P-PT,NPT	F-PT,NPT	A	E	F
PRB-04-02	1/4	1/8	22	8.0	9/16
PRB-06-04	3/8	1/4	23	11.0	11/16
PRB-08-04	1/2	1/4	28	11.0	7/8
PRB-08-06	1/2	3/8	28	15.0	7/8
PRB-12-04	3/4	1/4	31	11.0	1-1/16
PRB-12-06	3/4	3/8	31	15.0	1-1/16
PRB-12-08	3/4	1/2	31	18.0	1-1/16
PRB-16-08	1	1/2	35	18.0	1-3/8
PRB-16-12	1	3/4	35	22.0	1-3/8